

programming examples for different programming environments allowing you to use the proposed typical structure of the application.

## 8. DEFAULT LAN SETTINGS

1. Default IP: 192.168.50.152
2. Default Mask: 255.255.0.0
3. Default LAN port: 1024
4. Default HTTP port: 80
5. Default Gateway: 192.168.50.1
6. Default Login: AULNetLogin
7. Default Password: AULNetPass

Visit [www.tmatlantic.com](http://www.tmatlantic.com) for application notes, FAQs and software downloads



Watch video reviews and tutorials on T&M Atlantic's YouTube channel



## DC Power Supply

# APS-3320L / APS-3320LS APS-3610L / APS-3610LS

## User's Manual



## CONTENTS

1. Safety precautions .....	3
2. Description .....	3
2.1. Assignment .....	3
2.2. Terms of use .....	3
2.3. Technical characteristics and features .....	3
2.4. Accessories .....	4
2.5. Staff training .....	4
2.6. Controls .....	4
3. Preparation for work .....	5
4. Operation .....	5
4.1. Work in the current stabilization mode .....	5
4.2. Work in the voltage stabilization mode .....	5
5. Software .....	6
5.1. Software overview .....	6
5.2. PC connection .....	6
6. General information .....	7
6.1. Technical service .....	7
6.2. Fuse replacement .....	7
6.3. Cleaning .....	7
6.4. Storage and transportation .....	7
6.5. Technical support .....	7
7. Optional software .....	7
8. Default LAN settings .....	8

## 6. GENERAL INFORMATION

### 6.1. Technical service

**NOTE!** The following instructions are for qualified personnel only. To avoid electric shock, do not perform any other services other than those contained in the User manual.

### 6.2. Fuse replacement

When the fuse in the AC circuit gets out of order none of the LEDs are lit, and the power supply will not operate. Try to identify and eliminate the reason for the fuse blow, and only after that replace it with a fuse of the same type and with the same parameters. Fuse installation is made on the device rear panel.

### 6.3. Cleaning

Device cleaning should be done with a slightly damp flannel cloth soaked in soap solution. Before cleaning, make sure that the power cable of the device is taken off. If the device housing still has firm spots remained remove them with a cloth wiped with alcohol. After cleaning let the device dry completely. Avoid using solvents, such as benzene, etc.

### 6.4. Storage and transportation

Storage conditions: environment temperature: -20...+60 °C; relative air humidity is not more than 80 % with 25 °C. Transportation conditions: environment temperature: -20...+60 °C.

### 6.5. Technical support

For technical support visit [www.tmatlantic.com](http://www.tmatlantic.com).

Please send your questions and inquiries to: [marketing@tmatlantic.com](mailto:marketing@tmatlantic.com).

## 7. OPTIONAL SOFTWARE

Optional software:

1. AKTAKOM Power Manager Max Pro (APM Max Pro).
2. APS-3xxxLx\_SDK Software Development Kit.
3. APS-3xxxLx\_SDK\_Base Software Development Kit.

AKTAKOM Power Manager Max Pro is an application software to control AKTAKOM Power Supplies from a computer using an USB cable or a local area network (LAN). This software offers some advanced features, such as control templates, command lists, customizable user interface, event log, voice guide.

There are several advantages of APM Max Pro vs APM Max:

- Automatic control of the power supply output voltage and current in accordance with the pre-set sequence of commands;
- Event log (in text format);
- Measurement history graph;
- Customizable user interface: you can hide and collapse all the blocks of the main window you don't need and leave only the ones you need. Also you can choose to hide or show the manual control blocks, control presets, synchronization, news feeds. User interface settings can be saved and restored.

The APS-3xxxLx SDK is designed to help users in creating their own applications for the supported hardware. This SDK contains the device driver for controllable power supplies from the series of AKTAKOM Power Supplies APS-31xxL, APS-33xxL, APS-36xxL.

The driver contains all necessary functions for the device operation and represents dynamic-link library (DLL) Windows followed with the library header file in the C programming language, with LabWindows function tree and the tool library for LabVIEW which fully repeats it.

Additionally (in contrast to APS-3xxxLx\_SDK\_Base Software Development Kit) it contains the examples of programming in the following development environment: Borland C++ Builder, MS Visual C++, NI LabWindows/CVI and NI LabVIEW.

The driver library function can be also called from any programming environment with the ordinary for DLL method. As an example of such driver use there are projects for Borland C++ Builder 6, NI LabWindows/CVI and MS Visual C++ used.

The main advantage of the full SDK package is fast development of applications basing on the

voltage on the device output. If in the operating mode the load resistance change will cause the excess of the specified voltage limit, the device will automatically switch to the voltage stabilization mode with setting on terminals «+» and «-» of the preset voltage value limit, and the output current will proportionally fall.

3. By using CURRENT rotary switch set the maximum allowable current value (current limit value) for your load.
4. Connect the load to the device and press LOAD button. OUTPUT indicator should become red.
5. Before you disconnect the load press LOAD button. OUTPUT indicator will go out.
6. Before switching off the device, disconnect the load.

## 5. SOFTWARE

### 5.1. Software overview

The standard package of the device includes AKTAKOM Power Manager Max (APM Max) software. AKTAKOM Power Manager Max (APM Max) Software allows users to remotely control their AKTAKOM power supply via PC. It features Measure, Set Up and Initialization functions, as well as, automatic switching off of the outputs of the device at the end of the program. The program follows basic configurations and some features of operation as the device control panel. APM Max software provides control of output voltage and current in arbitrary (manual) mode as well as some advanced features including preset fixed voltage and current values and voice guide.

1. Software can be downloaded at [www.tmatlantic.com](http://www.tmatlantic.com) after registering the equipment with a serial number. Therefore follow Product registration link on [www.tmatlantic.com](http://www.tmatlantic.com).
2. PC installation of AKTAKOM Power Manager Max software is instructed on [www.tmatlantic.com](http://www.tmatlantic.com) and [www.aktakom.com](http://www.aktakom.com).

### 5.2. PC connection

Connection to the PC is made via USB or LAN located on the rear panel of APS-3320L / APS-3320LS / APS-3610L / APS-3610LS. The first connection to your PC should be made via USB interface. This will help to install the network parameters of your local network for the connection to the device. Installation instruction for the network parameters is given in HELP file.

1. For the device automatic search and connection it is not recommended to run AKTAKOM Power Manager Max Software after the PC installation but at first to connect the USB cable of APS-3320L / APS-3320LS / APS-3610L / APS-3610LS to the PC and then to run the program agreeing with the device automatic search. You may connect the device to the PC manually, see HELP file.
2. State (status) of the device remote control is indicated on the front panel with the connection indicator:
  - a. in the manual control mode — the indicator is OFF;
  - b. USB cable is connected (operation via USB) — the indicator is red;
  - c. LAN cable is connected (USB cable is disconnected) — the indicator is green;
  - d. there is “connected” mode set in the program (the device is operating in the remote control mode, the manual control is OFF) — the indicator is blinking in green or red color.
3. After interface connection, the network cable connection and active work of the local network the indicators of LAN socket should be blinking. Note: when you operate via LAN you need to DISCONNECT the USB cable.
4. USB interface takes priority. After you connect the USB cable the device can be controlled via the PC and the program connected via USB.
5. Please note! Be careful! Disconnection of the USB or LAN cable or the controlling program will return the voltage and current values which were set manually using «LOAD» button and the rotary switches on the front panel (Fig 1: 11, 12, 13). Always before entering the remote control mode it's recommended to switch off «LOAD» button.

If you have any questions concerning the use of interfaces or the software check the detailed description and the section with frequently asked questions at [www.tmatlantic.com](http://www.tmatlantic.com) and [www.aktakom.com](http://www.aktakom.com).

## 1. SAFETY PRECAUTIONS



**Follow the safety precautions!**

1. Prior to the device use carefully read this User manual.
2. Do not use in the presence of visible damage.
3. Repair and maintenance of the unit may only be undertaken by a specialist service center.
4. Before connecting the device to the mains observe all safety precautions to avoid electrical shock.
5. Use only those accessories that are designed for use with this product.
6. Before connecting the device to the electric network make sure in the correspondence of the power supply voltage to the mains voltage!
7. Do not turn on or off the device with the connected load.
8. Do not allow liquids on the cover of the device.

Safety symbols:



— high temperature



— high voltage

## 2. DESCRIPTION

### 2.1. Assignment

APS-3320L / APS-3320LS / APS-3610L / APS-3610LS (hereinafter — device) DC Regulated Power Supply provides accurate stable DC power. It is ideal for test benches, laboratories, schools and repair facilities. The multi-turn voltage control knob helps the user accurately dial in precise voltage. It is easy to read digital outputs (voltage & current) through a large display accurately. This product is expertly manufactured by AKTAKOM. It incorporates SMT PC boards and a cooling fan for reliable performance.

### 2.2. Terms of use

1. Supply and input voltage and the operation conditions are in accordance with the technical characteristics section.
2. There should be no dust, acid fume, alkali and gases capable of causing corrosion in the storage and operation areas.
3. Fall and vibration are not admitted.
4. After being in limiting conditions (storage, transportation) the device cure time in normal (operation) conditions is not less than 2 hours.

### 2.3. Technical characteristics and features

- Output voltage: 0...30 V (APS-3320L, APS-3320LS) / 0...60 V (APS-3610L, APS-3610LS)
- Output voltage accuracy:  $\pm(0.1\% + 2 \text{ digits})$
- Output voltage display resolution: 10 mV
- Output current: 0...20 A (APS-3320L, APS-3320LS) / 0...10 A (APS-3610L, APS-3610LS)
- Output current accuracy:  $\pm(0.1\% + 2 \text{ digits})$
- Output current display resolution: 10 mA
- Output power: 600 W
- Ripple and Noise: 5 mV
- Load stability:  $\pm(1\% + 10 \text{ mV})$
- Interface: USB Device, LAN
- Display: 2 LED displays
- Power supply: 110/220 V
- Dimensions: 10.4 × 5.5 × 14.2 in
- SMD technology
- Attractive digital display shows voltage and current
- Cooling fan
- High precision voltage regulation
- Progressive current regulation
- Dual terminal system: Safety test style or expandable screw terminals

- Overload protection circuit
- Output polarity: positive or negative
- Remote control via USB or LAN
- Rugged reinforced metal frame construction

## 2.4. Accessories

- |                          |        |
|--------------------------|--------|
| 1. Device.....           | 1 pcs. |
| 2. Power cord.....       | 1 pcs. |
| 3. Measuring cable ..... | 1 pcs. |
| 4. User manual.....      | 1 pcs. |
| 5. Package.....          | 1 pcs. |

*Note: Accessories of the device can be changed without notice. All declared functionality remains unchanged.*

## 2.5. Staff training

No special staff training for the device operation is required.

## 2.6. Controls



Fig.1. Front panel controls

1. Voltage indication
2. Current indication
3. +S output port
4. -S output port
5. -Output port
6. +Output port
7. -Output terminal
8. +Output terminal
9. Power switch
10. Output light
11. Output switch
12. Voltage adjustment rotary switch
13. Current adjustment pot
14. Additional output terminal\*: earth terminal
15. Remote control indicator



Fig. 2. Rear panel

[www.tmatlantic.com](http://www.tmatlantic.com)

16. Input port of the power cord
17. 110V / 220V switcher
18. LAN / USB sockets
19. Fuse holder
20. Cooling fan

\*Additional output terminals are designed for the voltage drop compensation on the connecting leads when there is a sufficient distance of the load from the power supply. Connection scheme with the use of the additional output terminals is shown below in Fig. 3.




Fig. 3.

## 3. PREPARATION FOR WORK

1. Connect the power cord to the device.
2. Connect the device to AC network with the standard cable to the socket equipped with a protective earth bus.
3. Turn VOLTAGE adjustment rotary switch counterclockwise until it stops.
4. Turn on the device by pressing POWER. The device switching on should light the digital indicators of the output voltage and current.
5. If OUTPUT indicator is red than press LOAD button. In that case OUTPUT indicator should go out and the current indicator will display the set current value. By using CURRENT knob set the average current value.
6. Turn VOLTAGE adjustment rotary switch clockwise until it stops to check that the output voltage is increased to maximum. Then turn it counterclockwise until it stops to ensure that the output voltage is reduced to 0V.
7. Set VOLTAGE adjustment rotary switch to the middle position.
8. Turn CURRENT knob clockwise until they stop in order to ensure that the current limit value can be set from zero to a maximum value.

## 4. OPERATION

### 4.1. Work in the current stabilization mode

1. If OUTPUT indicator is red than press LOAD button. In that case OUTPUT indicator should go out and the current indicator will display the set current value.
2. By using VOLTAGE adjustment rotary switch set the required output voltage (at the same time nothing should be connected to the output terminals «+» and «-»).
3. By using CURRENT rotary switch set the maximum allowable current value (current limit value) for your load. If in the operating mode the load resistance change will cause the excess of the specified current limit, the device will automatically switch to the current stabilization mode and the output voltage will proportionally fall.
4. Connect the load to the device and press LOAD button. OUTPUT indicator should become red.
5. Before you disconnect the load press LOAD button. OUTPUT indicator will go out.
6. Before switching off the device, disconnect the load.

### 4.2. Work in the voltage stabilization mode

1. If OUTPUT indicator is red than press LOAD button. In that case OUTPUT indicator should go out and the current indicator will display the set current value.
2. Adjust VOLTAGE adjustment rotary switches in order to obtain the maximum allowable load

[www.tmatlantic.com](http://www.tmatlantic.com)